

allowed clip distances

for the loading case wind uplift (closed hall)
a = allowed P/w


designation	normal range	border range	edge range
-------------	--------------	--------------	------------

h > 8,00 < 20,00m

t = 0,80mm	1,22m	0,66m	0,43m
------------	-------	-------	-------

⇒ for the normal and border range with a purlin spacing-axis of 676mm (according to architectural plans) the clip distances are sufficient.

But in the edge range (2,00 x 2,00), as an added measure, on each standard clip is a fixed point to be set. Each fixed point is to be set on the small and mid-rib with the blind rivet.



eaves panel 3D

title
eaves panel

RIB-ROOF
metalldachsysteme

Zambelli RIB-ROOF GmbH & Co. KG
Hans-Sachs-Str. 3+5, D-94569 Stephansposching
Tel. +49 (0)9931 89590-0
Fax +49 (0)9931 89590-49
e-mail: rib-roof@zambelli.de

system
RIB-ROOF 465

system accessories

drawing nr.
Z.2.20.03

index
A

drawn by V.K.	scale 1:10
date 01.10.02	format A3

zambelli

This drawing is copyright and remains the property of Zambelli. It must not be reproduced, used, disclosed or transmitted to third parties in any form, in whole or in part, without prior written permission.